LG V20 Loudspeaker Replacement

This is a replacement guide for the audio loudspeaker on the LG V20.

Written By: Elliot Mumma



INTRODUCTION


Are you tired of your LG V20 plying music that sounds distorted or is barely audible? The main speaker may be disconnected or damaged and require replacement. This guide will explain the steps needed to replace the speaker.

TOOLS:

- iFixit Opening Tools (1)
- Phillips #00 Screwdriver (1)

Step 1 — Battery





- Flip over the phone and lift the back cover off while pressing the small button on the bottom left side.

Step 2



- Place your thumb along the bottom of the battery and pull up to remove the battery.


Step 3 — Loudspeaker






- Use a screwdriver to remove the eight 4mm Philips #00 screws attaching the top and bottom frame sections to the phone.

Step 4






- Remove the top and bottom frame sections by applying force to one side of the frame until it pops off.

ⓘ The frame sections are held firmly to the phone by plastic clasps, so do not be afraid to apply pressure.

Step 5



- Using a blue plastic opening tool, gently pry up on the speaker to remove it.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-08-16 01:24:12 PM.

